



D

1. Demontieren Sie den unteren Stoßdämpferbolzen
2. Heben Sie das Fahrzeug an (achten Sie auf die Bremsschläuche) und demontieren Sie die Hauptfeder
3. Drehen Sie die Hilfsfeder von der Seite in die Hauptfeder. Siehe Bilder
4. Montieren Sie die oberen und unteren Federteller an der Hauptfeder und montieren Sie die Hauptfeder zusammen mit der Hilfsfeder am Fahrzeug
5. Lassen Sie das Fahrzeug herunter. Achten Sie darauf, dass die Hilfsfeder richtig über dem Federteller zentriert ist
Drehen Sie die Hilfsfeder so, dass das Windungsende an der Hinterseite des Fahrzeugs liegt. Siehe Bilder
6. Montieren Sie die untere Stoßdämpferbefestigung
7. Falls nötig, stellen Sie die Scheinwerfer neu ein.

GB

1. Remove the lower shock absorber bolts
2. Jack up the car (note the brake hoses) and remove the main spring
3. Turn the auxiliary spring into the mainspring from the side. See the pictures
4. Place the top and bottom spring seat onto the main spring and mount the main spring with the auxiliary spring on the car
5. Lower the car back on its wheels, take care that the auxiliary spring is centred correctly on the mainspring seats.
Turn the auxiliary spring so that the winding end is at the rear side of the car. See the pictures
6. Mount the shock absorber
7. Re-adjust the headlight beams.